

APEX® ITEMS:

- E-vapor battery
- Replacement e-vapor pre-filled tanks
- E-vapor micro-USB charging cable

WARNINGS AND INSTRUCTIONS

Please read these warnings and instructions carefully before using this product and retain them for future use.

WARNING: This product contains nicotine. Nicotine is an addictive chemical.

ADDITIONAL HEALTH INFORMATION:

- Nicotine can:
 - Harm your baby if you are pregnant or nursing.
 - Increase your heart rate and blood pressure and aggravate diabetes.
 - Cause dizziness, nausea, and stomach pain.
- Inhalation of this product may aggravate existing respiratory conditions.

WARNING: To reduce the risk of choking or poisoning:

- Keep the Apex® e-vapor device and items out of the reach of children.
- Do not use the Apex® battery or pre-filled tank if the packaging appears to have been tampered with.
- Dispose of Apex® e-vapor device and items properly. Refer to Disposal Instructions for further details.
- Each pre-filled tank contains nicotine which can be poisonous. In the event a pre-filled tank or any other item is ingested, call a Poison Control Center immediately. 1-800-222-1222.

WARNING: To reduce the risk of injury:

- If your Apex® battery or pre-filled tank appears to be leaking, do not use it. If the liquid comes in contact with the skin or eyes, wash with large amounts of water and seek medical advice.
- Your e-vapor device and items contain no user-serviceable parts. Do not attempt to open, service or repair; doing so may cause electric shock, thermal burns or fire.
- Do not use, store or charge any items in or near heat sources such as radiators, stoves, hot appliances or fires. High or low temperatures may cause battery fluid leakage, thermal burns, battery explosion or fire. Do not dispose of battery in fire.
- Do not use any Apex® items with any other manufacturer's e-vapor device items. Do not attempt to charge the Apex® battery with any other charging device. The Apex® e-vapor device should only be used with Apex® items.

WARNING: To reduce the risk of injury, do not use your Apex® e-vapor device or items if they:

- become wet or are immersed in any liquid.
- appear damaged or broken.
- have been exposed to excessive heat.
- are operating in an erratic manner.
- are unusually hot to the touch.

FCC STATEMENT

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception (a) when charging, which can be determined by disconnecting and then reconnecting the device to the charging source, or (b) when in use, which can be determined by drawing on and ceasing to draw on the device, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- If the equipment is connected to the charger, then connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Cease to use (i.e., cease drawing on) the device.

Changes or modifications not expressly approved by Nu Mark could void the user's authority to operate the equipment.

Use only for intended purposes.

MARKTEN® GUARANTEE

We stand by all MarkTen® e-vapor products. Every experience should meet your expectations. If it doesn't, we'll make it right. Call 1-855-MARKTEN for details.

LIMITED WARRANTIES

We warrant an Apex® by MarkTen® e-vapor pre-filled tank to function properly up to its "do not use after" date. We warrant all other Apex® items and accessories to function properly for six months from the date of purchase. These warranties do not apply to damage caused by any modification or alteration of the Apex® battery, pre-filled tanks or accessories or if damage is caused by use with pre-filled tanks or accessories from any other manufacturer. Please call 1-855-MARKTEN (1-855-627-5836) or go to MarkTen.com for details, including proof of purchase and age-verification requirements, regarding the MarkTen® Guarantee and the LIMITED WARRANTY offered on Apex® products.

APEX and MARKTEN are trademarks of Nu Mark LLC.
© 2017 Nu Mark LLC J0000

APEX®

by MARKTEN®

PRODUCT INFORMATION GUIDE

APEX® BY MARKTEN® OVERVIEW

The Apex® by MarkTen® pairs together a 1000mAh battery for maximum power with a convenient pre-filled tank system in a variety of flavors. The Apex® e-vapor device uses a ground breaking sub-ohm mesh heating system to ensure optimal vapor delivery. The advanced heater provides a consistent vapor experience throughout the life of each pre-filled tank.



Pre-filled tank

SECURE LOCK TECHNOLOGY

To ensure a durable connection between the pre-filled tank and the battery, Apex® e-vapor device uses secure lock technology. When you push the pre-filled tank onto the battery you will hear a "click" sound ensuring a perfect fit. Press forcefully until you hear the click.



Battery

FIRST USE GUIDE

Your battery comes partially charged, so you can use it right out of the box. For an optimal experience, charge fully before first use.



- 1) Securely lock your pre-filled tank onto battery.
- 2) Push button until LED illuminates.
- 3) Inhale from tank to vape. You do not need to keep the button pushed.
- 4) After 3 minutes of inactivity, the LED and battery will turn off.
- 5) To reactivate, push the button until the LED illuminates.



BATTERY LIFE INDICATORS

When you first turn on the battery, the LED will indicate the battery status.

LED Indicators:



Solid white LED = greater than 20% charge



LED slowly flashes white = 1%-20% charge



Solid red LED = 0% charge



You will also see solid red if your battery is depleted during use.

CHARGING YOUR APEX® BATTERY



1) Remove the pre-filled tank to gain access to the charging port. Store your pre-filled tank in a safe place.



2) Plug the micro USB cable into the port on the battery.



3) Connect the other end of the cable into a USB port.



4) The LED will blink white while the battery is charging.

5) The LED will turn off when the battery is fully charged.

6) Disconnect the micro USB from the battery prior to use.

LOCKING OUT YOUR APEX® BATTERY



- 1) In order to keep your battery from turning on unintentionally quickly press the button 5 times.
- 2) The LED will blink white multiple times to indicate the battery is locked out.
- 3) Repeat to unlock the device.



MONITORING YOUR LIQUID LEVEL



Every Apex® pre-filled tank comes full & has a semi-transparent window that allows viewing of the remaining liquid.

1) As you use your pre-filled tank the remaining liquid level will become visible.

2) Hold the pre-filled tank towards the ground. For better visibility, try holding the pre-filled tank up to a light.

3) When your pre-filled tank is almost empty, you will notice a reduction in vapor.

4) If the pre-filled tank is completely empty, the intelligent heating system will prevent the device from functioning and the LED indicator will blink red.



REPLACING YOUR APEX® PRE-FILLED TANKS

1) Forcefully pull the pre-filled tank from the battery.

2) Promptly discard the empty pre-filled tank responsibly to prevent injury or access by children or pets.

3) Securely lock a new pre-filled tank onto the battery.

4) Use only Apex® pre-filled tanks with your Apex® battery.

HANDLING AND CARE INFORMATION

- Clean Apex® items with a dry cloth.
- Keep all Apex® items dry. Do not immerse them in any liquid for any reason.
- Store Apex® items in a clean, dry, cool place. Do not store them in high temperatures or near fire or flames. Do not refrigerate or freeze items.
- Do not leave Apex® items unattended where children or pets could gain access to them.

DISPOSAL INSTRUCTIONS

- Dispose of used Apex® items responsibly.
- Your Apex® e-vapor device contains a Lithium-ion rechargeable battery. When discarded, it must be recycled or disposed of properly in accordance with state or local requirements. Do not crush battery (e.g., such as in a trash compactor). Do not dispose of any part of this product in fire or flame. For further information on recycling and disposal of the battery, call 1.877.2.RECYCLE (1.877.273.2925) or contact your local waste management officials.

MARKTEN® RECYCLING PROGRAM

You can also take advantage of our recycling programs for Apex® batteries and pre-filled tanks. To recycle pre-filled tanks call 1-855-MARKTEN to request a free MarkTen® recycling kit. Return postage is prepaid too. To recycle batteries, visit Call2Recycle.org or call 1.877.2.RECYCLE (1.877.273.2925) to find a participating Call2Recycle collection site and simply drop off your batteries at no cost to you.

Apex® outer packaging materials are made of PET plastic or paperboard and may be recyclable. Contact your local waste management officials to determine if your recycling center can recycle the packaging.

TROUBLESHOOTING

For troubleshooting information, please visit MarkTen.com or call 1-855-MARKTEN.

For additional information, please visit MarkTen.com or call 1-855-MARKTEN (1-855-627-5836).